


Group File List

Play Window



Media control bar with play, stop, previous, next, volume, and speed (1X) buttons.

Timeline bar with a scale from 0 to 24 and search/magnifying glass icons.